

Instructions for *Kwik Catch* Rod Holder

Ensure the bottom of the 4 magnet pads are clear of any debris that may have been picked up. The area for placement on the vehicle needs to be clean and free of dirt and dust before attaching the Kwik Catch unit.

The best and safest area to place your Kwik Catch unit is on the passenger side of the vehicle to avoid obstructing the driver's view.

Facing the vehicle from the front, identify the flattest surface area near the leading edge of the hood just to the left of its central point. This will allow the 4 base magnets to make the strongest contact, the magnetic feet will adjust some to compensate for a slight crown or rounded shape to the hood. Place the Kwik Catch base on the hood with the open end of the rod holder facing toward the rear of the vehicle, approximately 6" to 12" back from the leading edge of the hood and about equal distance to the left of its central point.



Loosen the 2 adjustment thumb-screws on the lower right side of the support base and raise the angle of the rod holder to its near maximum point. Be sure the flag-shaped lock mechanism in between the rod holders is flipped forward (*toward the front of the vehicle*) to the "unlocked" position.


Place a single rod in the left side holder and adjust the angle down toward the top, stopping when the fishing rod is about 1" above the vehicle's roof.

Tighten the thumb-screws a bit just to secure the rod at this angle but do not over tighten as there may be some final adjustments needed.



Ensure the bottom of the 2 magnet pads of the rod tip holder are clear of debris they may have picked up. Find the best and safest way to access the top of your vehicle near the passenger side just above the windshield.

Identify the front of the rod tip holder, look for the label located between the 2 halves of the holder.



Looking at the fishing rod, locate the point where the rod is closest to the vehicle's roof top and in a somewhat flat area to place the rod tip holding base.

Make note of the rod tip's positioning; place the tip holder (facing forward), over the rod and attach the base to the vehicle in the same location the rod was suspended above the rooftop.



Returning to the front of the vehicle, test the rod and holder for alignment and ease of use. Attempt to remove and re-install the rod to and from holder while grasping the handle portion of the rod above the reel. Minor adjustments to the rod holder base or the rod tip placement may be needed for the smoothest and most satisfactory performance. After making final adjustments, tighten the 2 thumb-screws on the lower right side of the rod holder base firmly, using only your fingers.



Make sure the rod holder lock is flipped toward the rear in the "locked" position. You are now ready to travel with your favorite fly rod.



*Product color may fade slightly in some cases but may be restored with an exterior protectant such as Armor All. Fading will not affect the product performance or durability.

For additional info and accessories please contact us at:

Kwik Catch

1133 N. Main Street; Ste. 213
Layton, UT 84041

e-mail: kwikcatch@comcast.net

or visit us on the web:

www.KwikCatch.com